

Butanox® M-60

Product description

Methyl ethyl ketone peroxide, solution in dimethyl phthalate

CAS No. : 1338-23-4 EINECS/ELINCS No. : 215-661-2

TSCA status : listed on inventory

Specifications

Appearance : Clear and colorless liquid

Total active oxygen : 9.8-10.0%

Characteristics

Density, 20°C : 1.170 g/cm³ Viscosity, 20°C : 25 mPa.s

Storage

Due to the relatively unstable nature of organic peroxides a loss of quality can be detected over a period of time. To minimize the loss of quality, AkzoNobel recommends a maximum storage temperature (T_s max.) for each organic peroxide product.

For Butanox M-60 T_s max. = 25°C

When stored under the recommended storage conditions, *Butanox* M-60 will remain within the AkzoNobel specifications for a period of at least 6 months after delivery.

Thermal stability

Organic peroxides are thermally unstable substances, which may undergo self-accelerating decomposition. The lowest temperature at which self-accelerating decomposition of a substance in the original packaging may occur is the Self-Accelerating Decomposition Temperature (SADT). The SADT is determined on the basis of the Heat Accumulation Storage Test.

For Butanox M-60 SADT: 60°C

The Heat Accumulation Storage Test is a recognized test method for the determination of the SADT of organic peroxides (see Recommendations on the Transport of Dangerous Goods, Manual of Tests and Criteria - United Nations, New York and Geneva).

Major decomposition products

Carbon dioxide, water, acetic acid, formic acid, propionic acid, methyl ethyl ketone.

Packaging and transport

The standard packaging is a 30 I HDPE can (Nourytainer®) for 30 kg peroxide solution.

In Asia Pacific the standard packaging is a 30 I HDPE can for 20 kg peroxide solution.

Both packaging and transport meet the international regulations. For the availability of other packed quantities contact your AkzoNobel representative.

Butanox M-60 is classified as Organic peroxide type D; liquid; Division 5.2; UN 3105.

Applications

Butanox M-60 is a general purpose methyl ethyl ketone peroxide (MEKP) for the curing of unsaturated polyester resins in the presence of a cobalt accelerator at room and elevated temperatures. Butanox M-60 is a 10% higher concentrated version of Butanox M-50.

The curing system *Butanox* M-60/cobalt accelerator is particularly suitable for the curing of gelcoat resins, laminating resins, lacquers and castings; moreover the manufacture of light resistant parts may be possible contrary to the curing system benzoyl peroxide/amine accelerator.

Practical experience throughout many years has proven that by the guaranteed low water content and the absence of polar compounds in *Butanox* M-60, this peroxide is very suitable in GRP products for e.g. marine applications.

For room temperature application it is necessary to use *Butanox* M-60 together with a cobalt accelerator (e.g. Accelerator NL-49P).

Dosage

Depending on working conditions, the following peroxide and accelerator dosage levels are recommended:

Butanox M-60 1 - 4 phr Accelerator NL-49P 0.5 - 3 phr

^{*} phr = parts per hundred resin

Cure Characteristics

In a high reactive standard orthophthalic resin in combination with Accelerator NL-49P (= 1% cobalt) the following application characteristics were determined:

Gel times at 20°C

2 phr <i>Butanox</i> M-60 + 0.5 phr Acc. NL-49P	10 minutes
2 phr <i>Butanox</i> M-50 + 0.5 phr Acc. NL-49P	12 minutes
2 phr <i>Butanox</i> M-60 + 1.0 phr Acc. NL-49P	6 minutes
2 phr <i>Butanox</i> M-50 + 1.0 phr Acc. NL-49P	7 minutes

Cure of 1 mm pure resin layer at 20°C

The speed of cure is expressed as the time to reach a Persoz hardness of respectively 30, 60 and 120 s.

	Persoz:	30	60	120	S
2 phr <i>Butanox</i> M-60 + 0.5 phr Acc. NL-49P 2 phr <i>Butanox</i> M-50 + 0.5 phr Acc. NL-49P		3.8 4.1		h h	
2 phr <i>Butanox</i> M-60 + 1.0 phr Acc. NL-49P 2 phr <i>Butanox</i> M-50 + 1.0 phr Acc. NL-49P		2.5 3.0	9 9.5	h h	

Cure of 4 mm laminates at 20°C

4 mm laminates have been made with a 450 g/m² glass chopped strand mat. The glass content in the laminates is 30% (w/w).

The following parameters were determined:

- Time-temperature curve.
- Speed of cure expressed as the time to achieve a Barcol hardness (934-1) of 0-5 and 25-30 respectively.
- Residual styrene content after 24 h at 20°C and a subsequent postcure of 8 h at 80°C.

	Gel time min.		Time Peal min.	k	Peak exotherm °C	
2 phr <i>Butanox</i> M-60 + 0.5 phr Acc. NL-49P 2 phr <i>Butanox</i> M-50 + 0.5 phr Acc. NL-49P	13 13		33 36		50 44	
2 phr <i>Butanox</i> M-60 + 1.0 phr Acc. NL-49P 2 phr <i>Butanox</i> M-50 + 1.0 phr Acc. NL-49P	7 8		23 26		71 64	
		arcol 25-30		24 h	Res. styrene 24 h + 8 h 20°C 80°C	
	h	h		%	%	
2 phr Butanox M-60 + 0.5 phr Acc. NL-49P						
2 phr <i>Butanox</i> M-50 + 0.5 phr Acc. NL-49P	2	13 15		5.7 6	0.3 0.3	

Pot life at 20°C

Pot lives were determined of a mixture of *Butanox* M-60 and a non-preaccelerated UP resin at 20°C.

2 phr *Butanox* M-60 10 h 4 phr *Butanox* M-60 6 h

Butanox and Nourytainer are registered trademarks of Akzo Nobel Chemicals B.V. or affiliates in one or more territories.

All information concerning this product and/or suggestions for handling and use contained herein are offered in good faith and are believed to be reliable. AkzoNobel Functional Chemicals, however, makes no warranty as to accuracy and/or sufficiency of such information and/or suggestions, as to the product's merchantability or fitness for any particular purpose, or that any suggested use will not infringe any patent. Nothing contained herein shall be construed as granting or extending any license under any patent. Buyer must determine for himself, by preliminary tests or otherwise, the suitability of this product for his purposes. The information contained herein supersedes all previously issued bulletins on the subject matter covered. The user may forward, distribute, and/or photocopy this document only if unaltered and complete, including all of its headers and footers, and should refrain from any unauthorized use. You may not copy this document to a website.

AkzoNobel Functional Chemicals Amersfoort, The Netherlands T +31 33 467 6767 F +31 33 467 6151

E polymerchemicals.nl@akzonobel.com

AkzoNobel Functional Chemicals Chicago, U.S.A. T+1 312 544 7000 1 800 828 7929 (Toll free US only) F+1 312 544 7188 E polymerchemicals.na@akzonobel.com Akzo Nobel (Asia) Co., Ltd. Shanghai, PR China T +86 21 2216 3600 F +86 21 3360 7739

E polymerchemicals.ap@akzonobel.com

www.akzonobel.com/polymer